

## **System Draining Instructions.**

Use these if the alarm system has been spiked.

1. Remove lid from main alarm unit.
2. Unplug PCB (printed circuit board).
3. Remove from case
4. Remove internal battery from PCB.
5. Remove In-Line fuse.

**Leave these parts out over a period of at least 6 hours, to allow the system to drain completely.**

With the bikes battery still in place and fully charged.

1. Replace PCB.
2. Replace In-Line fuse.
3. The alarm will sound for a period of aprox. 30 seconds.
4. Allow the system to reset itself.
5. Replace internal battery onto PCB.
6. Make sure all connections are complete.
7. Re-Align the remote – *Press and hold both buttons for a period of 5 seconds, then press the circle button.*